



1. Add glue to the hood.



2. Add glue to the tabs on the RACEPAK dash panel.



3. Install the front first and then the rear.

**4. Hold 3-5 mins to make sure the glue is dry.**