

1. Unbolt and remove your cluster.
2. Use a sharpie or marker and trace around the selected area (shown below).



3. Use an oscillating saw or equivalent to cut out selected area. Cut slowly and carefully. The black air vent box is directly behind the plate that you are cutting out.
4. Place the Classic Dash panel into your dash carrier and line it up with the mounting holes.
5. Use the attachment kit to mount the bezel into the dash carrier.